



# Safety instructions

## VEGATOR 131, 132

Installation in Zone 2  
with output intrinsic safety "i"



CE 0044



Document ID: 53596



# VEGA

## Contents

<b>1</b>	<b>Area of applicability.....</b>	<b>4</b>
<b>2</b>	<b>Device configuration/-properties .....</b>	<b>4</b>
<b>3</b>	<b>General information.....</b>	<b>4</b>
<b>4</b>	<b>Application area, use in gas and dust atmospheres.....</b>	<b>4</b>
<b>5</b>	<b>Special operating conditions.....</b>	<b>5</b>
<b>6</b>	<b>Safe operating mode .....</b>	<b>5</b>
<b>7</b>	<b>Important information for mounting and maintenance.....</b>	<b>5</b>
<b>8</b>	<b>Electrical data.....</b>	<b>6</b>
<b>9</b>	<b>Thermal data .....</b>	<b>7</b>
<b>10</b>	<b>Installation .....</b>	<b>7</b>

Supplementary documentation:

- Operating Instructions VEGATOR 131, 132
- EU-type approval certificate TÜV 16 ATEX 179411 X (Document ID: 53597)

Editing status: 2021-09-07

DE	Sicherheitshinweise für den Einsatz in explosionsgefährdeten Bereichen, verfügbar in den Sprachen deutsch, englisch, französisch und spanisch.
EN	Safety instructions for the use in hazardous areas are available in German, English, French and Spanish language.
FR	Consignes de sécurité pour l'utilisation en atmosphère explosible, disponibles dans les langues allemande, anglaise, française et espagnole.
ES	Instrucciones de seguridad para el empleo en áreas con riesgo de explosión, disponible en los siguientes idiomas alemán, inglés, francés y español.
CZ	Pokud nastanou potíže při čtení bezpečnostních upozornění v otištěných jazycích, poskytneme. Vám na základě žádosti k dispozici kopii v jazyce Vaší země.
DA	Hvis De har svært ved at forstå sikkerhedsforskrifterne på de trykte sprog, kan De få en kopi på Deres sprog, hvis De ønsker det.
EL	Εάν δυσκολεύεστε να διαβάσετε τις υποδείξεις ασφαλείας στις γλώσσες που ήδη έχουν τυπωθεί, τότε σε περίπτωση ζήτησης μπορούμε να θέσουμε στη διάθεσή σας ένα αντίγραφο αυτών στη γλώσσα της χώρας σας.
ET	Kui teil on raskusi trükitud keeltes ohutusnõuete lugemisega, siis saadame me teie järelpärimise peale nende koopia teie riigi keeles.
FI	Laitteen mukana on erikielisiä turvallisuuohjeita. Voit tilata meiltä äidinkielistet turvallisuusohjeet, jos et selviä mukana olevilla kielillä.
HU	Ha a biztonságos elõírásokat a kinyomtatott nyelveken nem tudja megfelelően elolvasni, akkor lépjen velünk kapcsolatba: azonnal a rendelkezésére bocsátunk egy példányt az Ön országában használt nyelven.
IT	Se le Normative di sicurezza sono stampate in una lingua di difficile comprensione, potete richiederne una copia nella lingua del vostro paese.
LT	Jeį Jums sunku suprasti saugos nuorodų tekstą pateiktomis kalbomis, kreipkitės į mus ir mes Jums duosime kopiją Jūsų šalies kalba.
LV	Ja Jums ir problēmas drošības noteikumus lasīt nodrukātajās valodās, tad mēs Jums sniegsim pēc pieprasījuma kopiju Jūsu valsts valodā.
MT	F'kaz li jkollok xi diffikulta' biex tifhem listruzzjonijiet ta' sigurta' kif ipprovduti, infurmana u ahna nibghatulek kopja billingwa tieghek.
NL	Als u moeite heeft met het lezen van de veiligheidsinstructies in de afgedrukte talen, sturen wij u op aanvraag graag een kopie toe in uw eigen taal.
PL	W przypadku trudności odczytania przepisów bezpieczeństwa pracy w wydrukowanych językach, chętnie udostępnimy Państwu kopię w języku obowiązującym w danym kraju.
PT	Caso tenha dificuldade de ler as instruções de segurança no idioma, no elas foram impressas, poderá solicitar junto a nós uma cópia em seu idioma.
SK	Pokiaľ nastanú problémy pri čítaní bezpečnostných pokynov vo vydaných jazykoch, poskytneme Vám na základe žiadosti k dispozícii kópiu v jazyku Vašej krajiny.
SL	Kadar se pojavijo težave pri branju varnostnih navodil v izdanih jeziki, vam bomo na osnovi zahtevka dali na razpolago kopijo v jeziku vaše države.
SV	Om du har problem att läsa säkerhetsanvisningarna på de här tryckta språken, ställer vi gärna på begäran en kopia på ditt språk till förfogande.

## 1 Area of applicability

These safety instructions apply to the devices:

- VEGATOR 131
- VEGATOR 132

In accordance with the EU type approval certificate TÜV 16 ATEX 179411 X (certificate number on type plate) and for all devices with safety instruction 53596.

The classification as well as the respective standards are stated in the above certificates:

Type of protection marking:

- II 3 (1) G Ex ec nC [ia Ga] IIC T4 Gc
- II 3 G (1) D Ex ec nC [ia IIIC Da] IIC T4 Gc
- II 3 G (M1) Ex ec nC [ia I Ma] IIC T4 Gc
- I (M1) [Ex ia Ma] I
- II (1) G [Ex ia Ga] IIC
- II (1) D [Ex ia Da] IIIC

## 2 Device configuration/-properties

The detailed device configurations can be retrieved using the serial number search on our homepage.

Move to "[www.vega.com](http://www.vega.com)" and enter in the search field the serial number of your instrument.

Alternatively, you can find all via your smartphone:

- Download the VEGA Tools app from the "Apple App Store", "Google Play Store" or "Baidu Store"
- Scan the DataMatrix code on the type label of the instrument or
- Enter the serial number manually in the app

## 3 General information

Die controllers VEGATOR 131.\*\*X\*\*\*\*, VEGATOR 131.\*\*S\*\*\*\* (with additional fail safe relay in the output) and the double channel controller VEGATOR 132 are used for intrinsically safe power supply of two-wire transmitters, the reliable galvanic separation from all other circuits and the processing of analogously transmitted measured data. The controllers VEGATOR 131, 132 depending on limit values are used for generation of binary output signals on the floating, non-contact relay output.

The VEGATOR 131, 132 are single or double channel controllers for conductive probes type EL. Applications are level detections and pump controls. In conjunction with multiple rod or cable probes, several VEGATOR 131, 132 can be combined with a probe.

The VEGATOR 131, 132 must be mounted and operated outside hazardous areas and inside hazardous areas zone 2.

The operating instructions as well as the installation regulations or standards that apply for explosion protection of electrical systems must generally be observed.

## 4 Application area, use in gas and dust atmospheres

### Category 3G

The VEGATOR 131, 132 must be mounted and operated outside hazardous areas and inside hazardous areas zone 2.

## 5 Special operating conditions

The following overview is listing all special properties of VEGATOR 131, 132, which make a labelling with the symbol "X" behind the certificate number necessary.

### Ambient temperature

You can find the details in chapter " *Thermal data*" of these safety instructions.

### Zone 2 applications

The device must be installed in a protective housing or a switching cabinet with IP54 according to EN 60079-0.

The device may only be used in an area with a minimum pollution level of 2 or better, as defined in EN 60664-1.

## 6 Safe operating mode

### General operating conditions

- Do not operate the instrument outside the electrical, thermal and mechanical specifications of the manufacturer

### Connection conditions

- The connection cable of VEGATOR 131, 132 has to be wired fix and in such a way that damages can be excluded
- If the temperature at the entry parts exceeds 70 °C, temperature-resistant connection cables must be used

## 7 Important information for mounting and maintenance

### General instructions

The following requirements must be fulfilled for mounting, electrical installation, setup and maintenance of the instrument:

- The staff must be qualified according the respective tasks
- The staff must be trained in explosion protection
- The staff must be familiar with the respectively valid regulations, e.g. planning and installation acc. to EN 60079-14
- Make sure when working on the instrument (mounting, installation, maintenance) that there is no explosive atmosphere present, the supply circuits should be voltage-free, if possible.
- The instrument has to be mounted according to the manufacturer specifications, the EU type approval certificate and the valid regulations and standards
- Modifications on the instrument can influence the explosion protection and hence the safety, therefore repairs are not permitted to be conducted by the end user
- Modifications must only be carried out by employees authorized by VEGA company
- Use only approved spare parts
- Components for installation and connection not included in the approval documents are only permitted if these correspond technically to the latest standard mentioned on the cover sheet. They must be suitable for the application conditions and have a separate certificate. The special conditions of the components must be noted and if necessary, the components must be integrated in the type test. This applies also to the components already mentioned in the technical description.

### Mounting

Keep in mind for instrument mounting

- Mechanical damage on the instrument must be avoided

- Mechanical friction must be avoided

### Maintenance

To ensure the functionality of the device, periodic visual inspection is recommended for:

- Secure mounting
- No mechanical damages or corrosion
- Worn or otherwise damaged cables
- No loose connections of the line connections, equipotential bonding connections
- Correct and clearly marked cable connections

### Intrinsic safety "i"

- Observe the valid regulations for the interconnection of intrinsically safe circuits.
- The instrument is only suitable for connection to certified, intrinsically safe instruments
- If the intrinsically safe circuit is led into dust-explosive areas of zone 20 or 21, please make sure that the instruments connected to these circuits meet the requirements of category 1D (EPL Da instruments) or 2D (EPL Db instruments) and are certified respectively

## 8 Electrical data

The VEGATOR 131, 132 include non-intrinsically safe circuits and one intrinsically safe circuit.

### Non-intrinsically safe circuit

<b>Supply circuit:</b>	
Connection 16/17	$U = 24 \dots 230 \text{ V AC } (-15 \dots +10 \%)$ $U = 24 \dots 65 \text{ V DC } (-15 \dots +10 \%)$ $U_m = 253 \text{ V AC}$

<b>Relay outputs:</b>	
10/11/12, 13/14/15	Maximum values: $253 \text{ V AC, } 3 \text{ A}$ $50 \text{ V DC, } 1 \text{ A}$

### Intrinsically safe circuit

<b>Signal circuit:</b>	
Connection 1/2, 4/5	Type of protection intrinsic safety Ex ia IIC, IIB, I Maximum values: $U_o \leq 12.6 \text{ V}$ $I_o \leq 7.7 \text{ mA}$ $P_o \leq 24.3 \text{ mW}$ Characteristics: Linear The effective internal inductance $L_i$ and capacity $C_i$ are negligibly small. The max. values of the table can also be used as concentrated capacitances and concentrated inductances. The values for IIC and IIB are also permitted for explosive dust atmospheres.

Ex ia I	L <sub>o</sub> [mH]	100	20	10	0.5	0.2
	C <sub>o</sub> [μF]	9.1	12	13	27	29
Ex ia IIC	L <sub>o</sub> [mH]	100	50	10	0.5	0.05
	C <sub>o</sub> [μF]	0.38	0.42	0.52	0.91	1.15
Ex ia IIB (IIIC)	L <sub>o</sub> [mH]	100	50	10	2	0.2
	C <sub>o</sub> [μF]	2.5	2.7	3.5	4.7	7.4

## 9 Thermal data

### Permissible ambient temperatures

Permissible ambient temperature at the installation location of an instrument	-20 ... +60 °C (-4 ... +140 °F)
---	---------------------------------

## 10 Installation

Controllers VEGATOR 131, 132 must be mounted and operated outside hazardous areas and inside hazardous areas zone 2. The protection rating of VEGATOR 131, 132 corresponds to IP20. If the controllers VEGATOR 131, 132 are not set up in dry and clean environments, they must be mounted in a housing with the required protection rating.

With zone 2 applications, the following special conditions must be noted:

According to EN/IEC 60079-7, paragraph H.2 the following applies for this instrument:

- For EPL Gc applications, the controllers VEGATOR 131 type TOR131.\*\*S/X\*\*\*\* and VEGATOR 132 type TOR132.\*\*\*\*\* must be integrated in such a way in a suitable housing acc. to EN/IEC 60079-7 or EN/IEC 60079-15 that a protection of at least IP54 is reached.
- For EPL Gc application, the controllers VEGATOR 131 type TOR131.\*\*S/X\*\*\*\* and VEGATOR 132 type TOR132.\*\*\*\*\* must be installed in such a way that a degree of pollution 2 or less acc. to IEC 60664-1 is reached.
- For EPL Gc applications, measures must be taken outside the controllers VEGATOR 131 type TOR131.\*\*S/X\*\*\*\* and VEGATOR 132 type TOR132.\*\*\*\*\* to ensure that the transient protection does not exceed the nominal voltage, connected to the supply terminals, by more than 40 %.
- For EPL Gc applications, connection and separating of non-intrinsically safe circuits is not permitted if there is no explosive atmosphere.

With zone 2 applications, the torque of the terminals should be between 0.5 Nm and 0.6 Nm.

The wire cross-section can be used between 0.2 mm<sup>2</sup> and 2.5 mm<sup>2</sup>.

Stripping length is 7 mm.

The housing used must be labelled with the following warning:

**WARNING – DO NOT SEPARATE WHEN ENERGIZED**

**WARNING – SEPARATE ONLY IN A NON-HAZARDOUS AREA**

If the intrinsically safe circuit is led into dust-explosive areas of zone 20 or 21, please make sure that the instruments connected to these circuits meet the requirements of category 1D or 2D and are certified respectively.

If the intrinsically safe circuit is led into firedamp endangered areas of group I category M1 or M2, please make sure that the instruments connected to these circuits meet the requirements of cat-

---

category M1 (EPL Ma instruments) or M2 (EPL Mb instruments) and are certified respectively.









Printing date:

**VEGA**

All statements concerning scope of delivery, application, practical use and operating conditions of the sensors and processing systems correspond to the information available at the time of printing.

Subject to change without prior notice

© VEGA Grieshaber KG, Schiltach/Germany 2022



53596-EN-220114

VEGA Grieshaber KG  
Am Hohenstein 113  
77761 Schiltach  
Germany

Phone +49 7836 50-0  
E-mail: [info.de@vega.com](mailto:info.de@vega.com)  
[www.vega.com](http://www.vega.com)