

## VEGABAR 18

Version, available since	Description	Device Rev.
2.0.0 01/2020	First version	1

### Legend:

Name	Description
Version	<p>xx.yy.zz</p> <p>xx: Compatibility version. Will be increased when the compatibility to the previous version is no longer given. Value range 0 ... 99.</p> <p>yy: Function extension version. Will be increased when new functions or function changes were carried out on the previous version. Also errors can have been corrected with a function change. Value range 0 ... 99.</p> <p>zz: Error correction version. Will be increased when only errors were corrected on the previous version. Value range 0 ... 99.</p>
available since	Month/Year
Device Rev.	<p>Version number of the instrument defined by Fieldbus.</p> <p>Consecutive integral number</p> <p>Will be increased if in the "Application Layer" modifications were carried out, e.g. new commands, modifications in the data structure in a command.</p>