

VEGAMIP R62/T61

Relay

Microwave receiver in separate version for level detection of bulk solids and liquids



Application area

The VEGAMIP T61 is the emitting unit, the VEGAMIP R62 the receiving unit of the microwave barrier in separate version for level detection of bulk solids and liquids. Typical applications are the detection of bulk solids in silos, bunkers and crushers as well as of liquids in pipelines and vessels. The non-contact measuring principle has no direct contact with the medium and ensures continuous wear-free and maintenancefree operation.

Your benefit

- Reliable measurement even with very abrasive products
- Separate instrument version enables mounting for hardly accessible installation locations
- · Reliable measurement even with changing product properties

Function

The measuring system consists of a microwave emitter and a corresponding receiver. The emitted signal is focused by an antenna system and radiated in the direction of the receiver. A medium in the path of the beam damps the signal. This signal damping is detected by the receiver and converted into a switching signal. The built-in sensitivity adjustment makes it easy to adapt the instrument to the local conditions and the medium.

Technical data

Process pressure -1 ... +4 bar/-100 ... +400 kPa

(-14.5 ... +58 psig)

Process temperature -40 ... +80 °C (-40 ... +176 °F) Process temperature with

mounting adapter

-40 ... +450 °C (-40 ... +842 °F)

Ambient, storage and

-40 ... +80 °C (-40 ... +176 °F)

transport temperature

approximately 1.33 dB

Hysteresis

Process fitting Thread from G11/2, 11/2, NPT, flanges,

Clamp

Operating voltage 20 ... 253 V AC, 50/60 Hz; 20 ... 72 V DC Power consumption 1 ... 8 VA (AC), approximately 1.5 W (DC)

Switching voltage max. 253 V AC/DC

Switching current max. 3 A AC (cos phi > 0.9), 1 A DC Breaking capacity min. 50 mW, max. 750 VA AC, 40 W DC

(with U < 40 V DC)

Materials

The wetted parts of the instrument are made of stainless steel 316L and PTFE. The optional mounting adapter for process temperatures up to 450 °C is made of 316L and has a cover of ceramic Al₂O₂.

You will find a complete overview of the available materials and seals in the "configurator" on our homepage at www.vega.com/configurator.

Housing versions

The housings are available in plastic, stainless steel or Aluminium.

They are available with protection ratings up to IP67.

Electronics versions

The receiving unit is available in different electronics versions. A transistor or a relay output with two floating spdts is possible.

Approvals

Worldwide approvals are available for VEGA instruments, e.g. for use in hazardous areas, on ships or in hygienic applications.


The technical data in the respective safety instructions are valid for approved instruments (e.g. with Ex approval). In some cases, these data can differ from the data listed herein.

You can find detailed information on the existing approvals with the appropriate product on our homepage.



Adjustment


You can adjust the mode and sensitivity of the level switch on the electronics module of the receiving unit (R). Control lamps indicate operation, switching status of the instrument and possible faults.



Electronics module receiving unit MP60EE.R - Relay output


- 1 Mode switch for selecting the switching behaviour (min./max.)
- 2 Control lamp (LED) for indication of a fault (red)
- 3 Signal lamp (LED) for indication of the switching status (yellow)
- 4 Control lamp (LED) for indication of the instrument function (green)
- 5 Connection terminals
- 6 Ground terminal
- 7 DIL switch for sensitivity adjustment (-->)
- 8 DIL switch for sensitivity adjustment (<--)
- 9 LED indicating board for indication of reception strength (yellow)

Electrical connection



Wiring plan, Receiving unit - VEGAMIP R62 R (receiver)

- 1 Relay output
- 2 Relay output
- 3 Voltage supply




Wiring plan, Emitting unit - VEGAMIP R62 T (transmitter)

1 Voltage supply

You can find details on electrical connection in the instrument operating instructions on our homepage at www.vega.com/downloads.

Dimensions



VEGAMIP R62

- 1 Receiving unit
- 2 External housing (evaluation unit)/Remote adjustment

Information

You can find further information on the VEGA product line on our homepage.

In the download section on our homepage you'll find operating instructions, product information, brochures, approval documents, instrument drawings and much, much more.

Software accessories such as the current device software and the appropriate operating software are also available there.

Instrument selection

On our homepage under "Products" you can select the suitable measuring principle and instrument for your application.

There you will also find detailed information on the available device versions.

Contact

You can find your personal contact person at VEGA on our homepage under "Contact".