
# VEGA

# **VEGABAR 86**

## 4 ... 20 mA/HART

# Submersible pressure transmitter with ceramic measuring cell



#### **Application area**

The VEGABAR 86 is a submersible pressure transmitter for level measurement in wells, basins and open vessels. Its great flexibility through different cable and tube versions allows the instrument to be used in many different applications.

The simple connection of VEGABAR series 80 sensors as electronic differential pressure opens up new possibilities for measuring differential pressures.

# Your benefit

- High plant availability through maximum overload and vacuum resistance of the ceramic measuring cell
- Self-cleaning effect thanks to front-flush design
- Low costs for maintenance thanks to wear-free ceramic measuring cell

## **Function**

The heart of the pressure transmitter is the pressure measuring cell transforming the pressure into an electrical signal. This pressure-dependent signal is convereted by the integrated electronics into a standardized output signal.

The sensor element with VEGABAR 86 is the CERTEC® measuring cell with excellent long-term stability and high overload resistance. The measuring cell is also equipped with a temperature sensor. The temperature value can be displayed via the display and adjustment module or processed via the signal output.

#### **Technical data**

Measuring ranges +0.1 ... +25 bar/+10 ... +2500 kPa

(+1.45 ... +363 psig)

Smallest measuring range +0.025 bar/+2.5 kPa (+0.363 psig)

Deviation < 0.1

Process fitting Straining clamp, threaded fitting, thread ab

G1½, 1½ NPT, flanges from DN 32, 1½"

Process temperature -20 ... +100 °C (-4 ... +212 °F)
Ambient, storage and -40 ... +80 °C (-40 ... +176 °F)

transport temperature

Operating voltage 9.6 ... 35 V DC

SIL qualification Optionally up to SIL2 (with homogeneous

redundancy up to SIL3)

#### **Materials**

The transmitter of the instrument is made of 316L or PVDF. The process seal consists of FKM, FFKM or EPDM, the suspension cable of PE, PUR or FEP.

You will find a complete overview of the available materials and seals in the " Configurator" at <a href="www.vega.com">www.vega.com</a> and " Products".

## **Housing versions**

The housings are available as single chamber or double chamber version in plastic, aluminium or stainless steel.

They are available in protection ratings up to IP68 (25 bar) with external electronics as well as in IP69K.

# **Electronics versions**

Apart from the two-wire electronics with 4  $\dots$  20 mA or 4  $\dots$  20 mA/ HART, also purely digital versions with Profibus PA, Foundation Fieldbus and are available. In addition a version as Secondary sensor is available for the electronic differential pressure measurement.

## Supplementary electronics

For instruments with double chamber housing two supplementary electronics such as radio module, a second current output or a power pack are available.

# **Approvals**

Worldwide approvals are available for VEGA instruments, e.g. for use in hazardous areas, on ships or in hygienic applications.

The technical data in the respective safety instructions are valid for approved instruments (e.g. with Ex approval). In some cases, these data can differ from the data listed herein.

You can find detailed information on the existing approvals with the appropriate product on our homepage.



#### **Adjustment**

## Adjustment directly at the measuring point

The adjustment of the instrument is carried out via the optional display and adjustment module PLICSCOM or via a PC with the adjustment software PACTware and corresponding DTM.

#### Wireless adjustment via Bluetooth

The Bluetooth version of display and adjustment module enables a wireless connection to standard adjustment units. This can be smartphones/tablets with iOS or Android operating system or PCs with PACTware and Bluetooth USB adapter.



Wireless connection to standard operating devices

Adjustment is hence carried out via a free-of-charge app from the Apple App Store or the Google Play Store or the adjustment software PACTware and respective DTM.




Adjustment via PACTware or app

# Adjustment via remote systems

Further adjustment options are possible via a HART Communicator as well as manufacturer-specific programs such as AMS™ or PDM.


## **Electrical connection**



Electronics and connection compartment, single chamber housing

- 1 Voltage supply/Signal output
- 2 For display and adjustment module or interface adapter
- 3 For external display and adjustment unit
- 4 Ground terminal for connection of the cable screening

#### **Dimensions**



- 1 Version with suspension cable and threaded fitting unassembled G11/2
- 2 Threaded version G11/2, suspension cable
- 3 Threaded version G1½, connection tube
- L Total length from configurator

## Information

You can find further information on the VEGA product line on our homepage.

In the download section of our homepage you'll find operating instructions, product information, industry brochures and approval documents as well as device and adjustment software.

## Instrument selection

On our homepage under " *Products*" you can select the suitable measuring principle and instrument for your application.

There you will also find detailed information on the available device versions.

## Contact

You can find your personal contact person at VEGA on our homepage under " Contact".