



Reliable

Certified materials according to FDA and EC 1935/2004 regulations

Cost effective

Accurate monitoring optimizes the brewing process

User friendly

One measuring instrument, three measured values: Level, overpressure, temperature

Fermentation tank

Level, pressure and point level measurement in the fermentation tank

After the wort has been cooled down to the appropriate temperature in the wort cooler, it is pumped into the fermentation tanks. The fermentation process is then started by adding in yeast. The yeast converts the malt sugar dissolved in the wort into carbonic acid and alcohol. To ensure optimal fermentation in the tank, the following key parameters are measured: hydrostatic pressure for determining the level, overpressure for CO₂ content monitoring and limit level for overflow or dry run protection.

More details



VEGABAR 82

Level measurement via electronic differential pressure measurement in the fermentation tank

- Reliable measurement unaffected by condensation thanks to encapsulated measuring cell
- Good cleanability thanks to hygienic design and flush mounting
- Additional temperature measurement by temperature sensor located very close to the process

[Show Product](#)



VEGABAR 38

Pressure sensor for pressure monitoring in the yeast supply line and in the CO₂ discharge line

- Ceramic CERTEC® measuring cell is resistant to CIP cleaning
- Good cleanability thanks to hygienic design
- Bluetooth communication for easy operation

[Show Product](#)



VEGAPOINT 21

Capacitive level switch as overflow and dry run protection in the fermentation tank

- 360° status display for quick and easy recognition of switching status
- Compact design facilitates cleaning
- Reliable measurement independent of condensation and foam

[Show Product](#)



PRO

VEGABAR 82
[Show Product](#)



Measuring range - Distance
-

Measuring range - Pressure
-1 ... 100 bar

Process temperature
-40 ... 150 °C

Process pressure
-1 ... 100 bar

Accuracy
0.05 %

Materials, wetted parts
PVDF
316L
Alloy C22 (2.4602)
PP
1.4057
1.4410
Alloy C276 (2.4819)
Duplex (1.4462)
Titanium Grade 2 (3.7035)

Threaded connection
≥ G½, ≥ ½ NPT

Flange connection
≥ DN15, ≥ ½"

Hygienic fittings
Clamp ≥ 1" - DIN32676, ISO2852
Slotted nut ≥ DN25 - DIN 11851
hygienic fitting with tension flange DN32
hygienic fitting F40 with compression nut
DRD connection ø 65 mm
SMS 1145 DN51
SMS DN38
Swagelok VCR screwing
Varivent G125
Varivent N50-40
for NEUMO BioControl D50 PN16 / 316L

Seal material
EPDM
FKM
FFKM

BASIC

VEGABAR 38
[Show Product](#)



Measuring range - Pressure
-1 ... 60 bar

Process temperature
-40 ... 130 °C

Accuracy
0.3 %

Materials, wetted parts
PVDF
316L
Duplex (1.4462)
Ceramic

Threaded connection
≥ G½, ≥ ½ NPT

Hygienic fittings
Clamp ≥ 2", DN50 - DIN32676, ISO2852
Clamp ≥ 1" - DIN32676, ISO2852
Clamp ≥ ½" - DIN32676, ISO2852
Slotted nut ≥ ½", ≥ DN40 - DIN 11851
Slotted nut ≥ DN25 - DIN 11851
SMS DN38
Hygienic fittings ≥ DN25 - DIN11864-1-A
Hygienic fittings ≥ DN40 - DIN11864-1-A
Varivent N50-40
SMS DN25
Ingold connection PN10
Varivent F25

Seal material
EPDM
FKM
FFKM

Housing material
Plastic

Protection rating
IP66/IP67
IP65

Output
4 ... 20 mA
Three-wire (PNP/NPN, 4 ... 20 mA)
IO-Link

BASIC

VEGAPOINT 21
[Show Product](#)



Measuring range - Distance
-

Process temperature
-40 ... 115 °C

Process pressure
-1 ... 64 bar

Materials, wetted parts
316L
PEEK

Threaded connection
≥ G½, ≥ ½ NPT

Hygienic fittings
Clamp ≥ 2", DN50 - DIN32676, ISO2852
Clamp ≥ 1" - DIN32676, ISO2852
Clamp ≥ ½" - DIN32676, ISO2852
Slotted nut ≥ ½", ≥ DN40 - DIN 11851
Slotted nut ≥ DN25 - DIN 11851
Slotted nut ≥ DN32 - DIN 11851

Seal material
EPDM
FKM

Protection rating
IP66/IP67
IP69

Output
Transistor (NPN/PNP)
IO-Link

Ambient temperature
-40 ... 70 °C