



### Reliable

Certified materials according to FDA and EC 1935/2004 regulations

### Cost effective

Accurate monitoring optimizes the brewing process

### User friendly

One measuring instrument, three measured values: Level, overpressure, temperature

## Fermentation tank

### Level, pressure and point level measurement in the fermentation tank

After the wort has been cooled down to the appropriate temperature in the wort cooler, it is pumped into the fermentation tanks. The fermentation process is then started by adding in yeast. The yeast converts the malt sugar dissolved in the wort into carbonic acid and alcohol. To ensure optimal fermentation in the tank, the following key parameters are measured: hydrostatic pressure for determining the level, overpressure for CO<sub>2</sub> content monitoring and limit level for overflow or dry run protection.

#### More details



### VEGABAR 82

Level measurement via electronic differential pressure measurement in the fermentation tank

- Reliable measurement unaffected by condensation thanks to encapsulated measuring cell
- Good cleanability thanks to hygienic design and flush mounting
- Additional temperature measurement by temperature sensor located very close to the process

[Show Product](#)



### VEGABAR 38

Pressure sensor for pressure monitoring in the yeast supply line and in the CO<sub>2</sub> discharge line

- Ceramic CERTEC® measuring cell is resistant to CIP cleaning
- Good cleanability thanks to hygienic design
- Bluetooth communication for easy operation

[Show Product](#)



### VEGAPOINT 21

Capacitive level switch as overflow and dry run protection in the fermentation tank

- 360° status display for quick and easy recognition of switching status
- Compact design facilitates cleaning
- Reliable measurement independent of condensation and foam

[Show Product](#)



## PRO

**VEGABAR 82**  
[Show Product](#)

**Measuring range - Distance**

-

**Measuring range - Pressure**

-1 ... 100 bar

**Process temperature**

-40 ... 150 °C

**Process pressure**

-1 ... 100 bar

**Accuracy**

0.05 %

**Materials, wetted parts**

PVDF  
 316L  
 Alloy C22 (2.4602)  
 PP  
 1.4057  
 1.4410  
 Alloy C276 (2.4819)  
 Duplex (1.4462)  
 Titanium Grade 2 (3.7035)

**Threaded connection**

≥ G½, ≥ ½ NPT

**Flange connection**

≥ DN15, ≥ ½"

**Hygienic fittings**

Clamp ≥ 1" - DIN32676, ISO2852  
 Slotted nut ≥ DN25 - DIN 11851  
 hygienic fitting with tension flange DN32  
 hygienic fitting F40 with compression nut  
 DRD connection ø 65 mm  
 SMS 1145 DN51  
 SMS DN38  
 Swagelok VCR screwing  
 Varivent G125  
 Varivent N50-40  
 for NEUMO BioControl D50 PN16 / 316L

**Seal material**

EPDM  
 FKM  
 FFKM

## BASIC

**VEGABAR 38**  
[Show Product](#)

**Measuring range - Pressure**

-1 ... 60 bar

**Process temperature**

-40 ... 130 °C

**Accuracy**

0.3 %

**Materials, wetted parts**

PVDF  
 316L  
 Duplex (1.4462)  
 Ceramic

**Threaded connection**

≥ G½, ≥ ½ NPT

**Hygienic fittings**

Clamp ≥ 2", DN50 - DIN32676, ISO2852  
 Clamp ≥ 1" - DIN32676, ISO2852  
 Clamp ≥ ½" - DIN32676, ISO2852  
 Slotted nut ≥ ½", ≥ DN40 - DIN 11851  
 Slotted nut ≥ DN25 - DIN 11851  
 SMS DN38  
 Hygienic fittings ≥ DN25 - DIN11864-1-A  
 Hygienic fittings ≥ DN40 - DIN11864-1-A  
 Varivent N50-40  
 SMS DN25  
 Ingold connection PN10  
 Varivent F25

**Seal material**

EPDM  
 FKM  
 FFKM

**Housing material**

Plastic

**Protection rating**

IP66/IP67  
 IP65

**Output**

4 ... 20 mA  
 Three-wire (PNP/NPN, 4 ... 20 mA)  
 IO-Link

## BASIC

**VEGAPOINT 21**  
[Show Product](#)

**Measuring range - Distance**

-

**Process temperature**

-40 ... 115 °C

**Process pressure**

-1 ... 64 bar

**Materials, wetted parts**

316L  
 PEEK

**Threaded connection**

≥ G½, ≥ ½ NPT

**Hygienic fittings**

Clamp ≥ 2", DN50 - DIN32676, ISO2852  
 Clamp ≥ 1" - DIN32676, ISO2852  
 Clamp ≥ ½" - DIN32676, ISO2852  
 Slotted nut ≥ ½", ≥ DN40 - DIN 11851  
 Slotted nut ≥ DN25 - DIN 11851  
 Slotted nut ≥ DN32 - DIN 11851

**Seal material**

EPDM  
 FKM

**Protection rating**

IP66/IP67  
 IP69

**Output**

Transistor (NPN/PNP)  
 IO-Link

**Ambient temperature**

-40 ... 70 °C