

#### Reliable

Optimal concentration thanks to highly accurate level measurement

#### Cost effective

Easy cleaning without dismantling

#### **User friendly**

Simple installation and setup



### Vacuum evaporator with scraper system

# Level measurement in a vacuum evaporator with scraper system and pressure monitoring in the supply line

A thickening vessel fitted with a scraper is used to increase the concentration of extracted solutions by means of evaporation under vacuum. Extremely precise level measurement is required in this process because the concentration is determined by the filling height. The evaporation system operates according to meeting specified levels. As soon as they reach the correct value, the evaporation process is stopped and the concentrated solution is discharged out of the tank.

#### More details



#### **VEGABAR 38**

Pressure monitoring with IO-Link connection in the supply line of the heating medium

- Reliable measurement thanks to fast response time
- Robust ceramic CERTEC® measuring cell guarantees a long service life
- Simple operation thanks to VDMA menu structure and integrated display

#### **Show Product**



#### **VEGAPULS 6X**

Vacuum evaporator level measurement with non-contact radar

- Measurement down to the bottom of the vessel thanks to tight signal focusing
- Reliable measurement, unaffected by vessel internals due to high dynamic range
- Encapsulated antenna system, insensitive to condensation and buildup
- The front-flush, encapsulated antenna is easy to clean and resistant to the extreme conditions of the CIP and SIP processes

#### **Show Product**



## **VEGABAR 38 Show Product**



Measuring range - Pressure

-1 ... 60 bar

Process temperature

-40 ... 130 °C

Accuracy

0.3 %

Materials, wetted parts

PVDF 316L

Duplex (1.4462)

Ceramic

Threaded connection

≥ G½, ≥ ½ NPT

Hygenic fittings

Clamp ≥ 2", DN50 - DIN32676, ISO2852

Clamp ≥ 1" - DIN32676, ISO2852

Clamp ≥ 1½" - DIN32676, ISO2852

Slotted nut ≥ 1½", ≥ DN40 - DIN 11851

Slotted nut ≥ DN25 - DIN 11851

SMS DN38

Hygienic fittings ≥ DN25 - DIN11864-1-A

Hygienic fittings ≥ DN40 - DIN11864-1-A

Varivent N50-40

SMS DN25

Ingold connection PN10

Varivent F25

Seal material

**EPDM** 

FKM FFKM

Housing material

Plastic

Protection rating

IP66/IP67

IP65

Output

4 ... 20 mA Three-wire (PNP/NPN, 4 ... 20 mA)

IO-Link

**VEGAPULS 6X** 

**Show Product** 



Measuring range - Distance

120 m

Process temperature

-196 ... 450 °C

Process pressure

-1 ... 160 bar

Accuracy

± 1 mm

Frequency

6 GHz

26 GHz

80 GHz

Beam angle

≥ 3°

Materials, wetted parts

PTFE

PVDF

316L

PP PEEK

Threaded connection

≥ G¾, ≥ ¾ NPT

Flange connection

≥ DN20, ≥ ¾"

Hygenic fittings

Clamp  $\geq 1\frac{1}{2}$ " - DIN32676, ISO2852

Slotted nut ≥ 2", DN50 - DIN 11851

Varivent ≥ DN25

hygienic fitting with tension flange DN32

hygienic fitting F40 with compression nut

Hygienic screw connections  $\geq$  DN50 tube ø53 -

DIN11864-1-A

Hygienice flange connection ≥ DN50 DIN11864-2

Hygienic clamp connection ≥ DN50 pipe Ø53 - DIN11864-

3-A

DRD connection ø 65 mm

SMS 1145 DN51

