



## **VEGATOR 121/122**

Version, available since	Description
1.3.1, 08/2021	New functions (exclusively for VEGATOR 121.**S****):  - Logic gate changed to Schmitt trigger input
1.3.0, 04/2018	New functions (exclusively for VEGATOR 121.**S****): - Switching over possibility of output 2 between fail safe and function relay.
1.2.1, 08/2021	Error corrections (VEGATOR 122. and VEGATOR 121.**X****): - Logic gate changed to Schmitt trigger input
1.2.0, 11/2014	Error corrections:  - Relay type 24 V changed to 18 V pull-in voltage  Downward compatibility given (the middle index was incremented by mistake)
1.1.1, 08/2014	<ul> <li>Error corrections:</li> <li>Preventative measure to avoid problems through batch variation of components in the measured value processing.</li> </ul>
1.1.0, 07/2014	New functions:  - SIL available  - Switching on impulse monitoring of the measured value decoupled
1.0.1, 06/2014	Error corrections:  - Preventative measure to avoid problems through batch variation of components in the measured value processing.
1.0.0, 02/2014	First version





## Legend:

Name	Description
Version	<ul> <li>xx.yy.zz</li> <li>xx: Compatibility version. Will be increased when the compatibility to the previous version is no longer given. Value range 0 99.</li> <li>yy: Function extension version. Will be increased when new functions or function changes were carried out on the previous version. Also errors can have been corrected with a function change. Value range 0 99.</li> <li>zz: Error correction version. Will be increased when only errors were corrected on the previous version. Value range 0 99.</li> </ul>
available since	Month/Year